

Running Boards SUV Side Steps suitable for BMW X6 F16 (2014-2019)

Code RBBMF16



To facilitate your installation, please read the product instruction manual carefully before installation.

Step 1: Remove the original side skirts of the car (please keep the nuts and buckles to fix the new boards).



Step 2: Install our inner brackets on the car and tighten it with the existed screws

Step 3: Fix the bracket with screws



Step 4: Check whether all screws are tightened and pack the tools.

Step 5: Fix the outer boards on the bracket installed



Step 6: Repeat on the other side

Disclaimer: Our company is not responsible for any related problems and losses caused by improper installation and use.